

HOW TO CONNECT YOUR TV TO YOUR NEOWARE COMPUTER WITH THE AVERKEY BOX...



1. The black AV cable goes from the front of the TV video slot to the left side of the AverKey media box.



2. Disconnect your computer monitor cable (has a blue end on it) and plug into the AverKey media box in the "VGA out" slot (left hand slot).



3. Take one end of the black VGA cable that came with the AverKey media box and plug it into the 3rd cable slot (blue) on the back of your Neoware box. Plug the other end of this VGA cable into the back of the AverKey media box in the "VGA In" slot (right hand slot).

You're almost done...

4. Plug in the power cord for the AverKey box from the back of the unit to an outlet.
5. TV needs to be on Ch. 3.
6. Also, if the screen is not displaying what's shown on your computer, push MENU on the TV once and use channel +/- to choose the input and make sure the "input" shows "Video-3".

Setting up your AverKey media box this way will allow you to view what's on your computer screen AND the TV at the same time. You could leave this set up all of the time and not need to ever unhook this.